


### Compashield Solid O-strip:

Solid O-strip is a universal, very common type of gasket. Easy to use, easy to assemble. Normally moulded in a groove.



Solid O-strip Soft is a variant developed by Nolato that has a core of very soft elastic pure silicone and an outside layer of our conductive silicones to achieve excellent shielding properties. The Solid O-strip Soft offers better mechanical properties than the standard type, especially compression set, and has lower compression force.

Both types can in an economical way be delivered spliced into endless O-rings by use of the patented Compashield Splicing Tool. This can in many application be an advantage to make assembly easier and to ensure that no gap can occur over time.



#### Nolato Silikonteknik AB

**Europe**

+46 582 88900

**China**

+86 186 008 8696

**Malaysia**

+60 16 743 5988

**India**

+91 98847 22707

**USA**

+1 651 955 9505

[www.nolato.com/silikonteknik](http://www.nolato.com/silikonteknik)